



NOTES:

1. SERVICE CLEANOUT TO BE SAME DIAMETER AND MATERIAL AS SERVICE LATERAL.
2. USE OLYMPIC FOUNDRY 8"X4" CLEANOUT RING & COVER PART #M1007 OR APPROVED EQUAL
3. LOCATION:
 - A. WHERE NEW CURB IS BEING INSTALLED OR EXISTING CURB IS PRESENT AND A PLANTER AREA IS OR WILL EXIST BETWEEN CURB AND SIDEWALK, CLEANOUT SHALL BE PLACED 2 FEET BEHIND CURB.
 - B. WHEN A PLANTER AREA DOES NOT EXIST (i.e. CURB TIGHT SIDEWALK), THE CLEANOUT SHALL BE 12 INCHES FROM BACK OF SIDEWALK TO CENTER OF CLEANOUT.
 - C. WHEN NO CURB OR SIDEWALK EXISTS, LOCATE CLEANOUT 1 FOOT INSIDE RIGHT OF WAY LINE OR AS DIRECTED BY THE ENGINEER.
 - D. WHERE CURB EXISTS BUT NO SIDEWALK, CLEANOUT SHALL BE PLACED 2 FEET BEHIND CURB.
4. VIDEO INSPECT ALL LATERALS FROM MAINLINE TO CLEANOUT/ROW LINE, OR FROM CLEANOUT/ROW LINE TO MAINLINE, PER APPLICABLE APWA/ODOT STANDARDS.



Public Works Standard Drawings

2-WAY CLEANOUT FOR SANITARY SEWER SERVICE

| | |
|--------------|-----------|
| SCALE | NTS |
| DATE JAN '24 | REV. 1 |
| ENGR. DW | DRAWN KAE |
| DRAWING NO. | 310-A |